




SmartGen
ideas for power

HAT163

ATS CONTROLLER

USER MANUAL



SMARTGEN (ZHENGZHOU) TECHNOLOGY CO.,LTD.



Chinese trademark

SmartGen English trademark

SmartGen — make your generator *smart*

SmartGen Technology Co., Ltd.

No. 28 Jinsuo Road

Zhengzhou

Henan Province

P. R. China

Tel: 0086-371-67988888/67981888

0086-371-67991553/67992951

0086-371-67981000(overseas)

Fax: 0086-371-67992952

Web: www.smartgen.com.cn

www.smartgen.cn

Email: sales@smartgen.cn

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to SmartGen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

Table 1 - Software Version

Date	Version	Content
2018-05-20	1.0	Original release

CONTENTS

1. OVERVIEW	4
2. PERFORMANCE AND CHARACTERISTICS	4
3. SPECIFICATION.....	5
4. OPERATION	6
4.1 FRONT PANEL DESCRIPTION	6
4.2 KEY FUNCTION DESCRIPTION.....	6
4.3 INDICATOR DESCRIPTION.....	7
4.4 OPERATION	7
4.4.1 AUTO/MANUAL MODE SWITCH	7
4.4.2 MANUAL OPERATION	7
4.4.3 AUTO OPERATION	8
4.4.4 MANUAL TEST	8
5. CLOSE FAULT ALARM.....	8
6. CONNECTION	8
7. DEFINITION AND RANGE OF PARAMETERS	10
8. PARAMETERS SETTING.....	13
8.1 PARAMETERS SETTING MODE.....	13
8.2 PARAMETERS SETTING.....	13
8.3 RESET TO DEFAULT	14
9. TYPICAL APPLICATION	15
10. OVERALL DIMENSION AND PANEL CUTOUT	19
10.1 CASE DIMENSION	19
10.2 CUTOUT	19
10.3 INSTALLATION.....	20
11. TROUBLESHOOTING.....	21

1. OVERVIEW

HAT163 ATS Controller is suitable for one breaking three stage ATS. It can accurately detect 2-way-3-phase voltage and judge voltage abnormal (such as over voltage, under voltage, over frequency, under frequency, lack of phase and phase rotation), and then control ATS to switch. In auto mode, if source 1 failure, controller will send signal to start the genset. Moreover, it can also realize remote communication, remote control and parameter configuration functions via LINK port communication.

2. PERFORMANCE AND CHARACTERISTICS

HAT163 controller can detect 2-way voltage (2-way mains, 1-way mains and 1-way gen) and control ATS.

Mains characters are as below,

- It is suitable for AC system with 3-phase 4-wire, 2-phase 3-wire, single phase, and 3-phase 3-wire (special order required);
- “Source 1 Main (auto transfer and restore)”, “Source 2 Main (auto transfer and restore)”, and “No Main Use (auto transfer and non-auto restore)” power supply methods;
- Measuring and displaying 2-way voltage and frequency:

1#	2#
Phase voltage (Ua, Ub, Uc)	Phase voltage (Ua, Ub, Uc)
Line voltage (Uab, Ubc, Uca)	Line voltage (Uab, Ubc, Uca)
Frequency Hz	Frequency Hz
- With over/under voltage, over/under frequency, loss of phase, and phase rotation detection functions;
- LEDs on the panel can clearly display ATS working status;
- Auto/Manual mode can be switched. In manual mode, ATS can be switched by pressing front panel button;
- With one force open input port (fire reset function);
- With manual commissioning function;
- Applicable for 2 isolated neutral line.
- Close output can be configured as pulse and continuous output;
- If A-phase voltage of any one way is normal, both controller and ATS can be worked. When A-phase voltage is normal, if the two power supply voltages are abnormal at the same time, ATS will automatically switch to the breaking position;
- Parameter setting: parts of parameters can be adjusted from front panel; all can be adjusted via LINK port(with SG72 adaptor) by using computer software;
- Digitization adjustment of parameters (abandon simulation adjustment of regular potentiometer, and enhanced reliability and stability);
- Modular design, self extinguishing ABS+PC plastic shell, pluggable terminal, and compact structure;
- Three installation ways: panel built-in, internal 35mm slideway installation and internal screw mounting.

3. SPECIFICATION

Table 2 – Specification Parameters

Items	Contents
Operating Voltage	AC power A1N1/A2N2 supply. Rated 240VAC (range: AC170V~AC277V)
Power Consumption	Under rated voltage, power consumption is not more than 3VA
AC Voltage Input:	
3-phase 4-wire	AC170V – AC277V (ph-N)
2-phase 3-wire	AC170V – AC277V (ph-N)
Single phase 2-wire	AC170V – AC277V (ph-N)
3-phase 3-wire	AC170V – AC277V (ph-ph) (special order required)
AC Frequency	50/60Hz
1# Close Relay	10A/250VAC Volt free output (Normally open)
2# Close Relay	10A/250VAC Volt free output (Normally open)
Breaker Open Relay	7A /250VAC Volt free output (Normally open)
Oil Engine Start Relay	7A /250VAC Volt free output (Normally close)
LO/NO Relay	10A/250VAC Active output
Communication	LINK interface, MODBUS-RTU Protocol
Case Dimensions	86.9mmx158mmx119.5mm
Panel Cutout	73.5mmx144mm
Working Conditions	Temperature: (-25~+70)°C; Relative Humidity: (20~93)%RH
Storage Condition	Temperature: (-25~+70)°C
Protection Level	IP65: when water-proof gasket installed between control panel and enclosure.
Isolation Strength	Apply AC1.5kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.
Weight	0.7kg

4. OPERATION

4.1 FRONT PANEL DESCRIPTION




Fig.1 – Front Panel Description

4.2 KEY FUNCTION DESCRIPTION

Table 3 – Keys Description

Icon	Function	Description
	Auto (Set)	Auto/Manual mode switch; Enter into lamp test status by pressing for 3s; Enter into parameter configuration mode by pressing for 8s.
	1# Close (Numerical increase)	1# close in manual mode; Adjust parameters in parameter configuration mode.
	2# Close (Numerical decrease)	2# close in manual mode; Adjust parameters in parameter configuration mode.
	Open	Used for opening breaker in manual mode..
	Test (Confirm)	It is active in manual mode; While genset start signal is energizing, press this button can deactivate the start genset signal; While genset start signal is inactive, press this button can active the genset start signal; Confirm user defined parameters in parameter setting screen.



4.3 INDICATOR DESCRIPTION

Tale 4 – Indicator Description

Indicators	Description	
1# Power ●	Lamp illuminates: 1# power normal Lamp flashes: 1# power abnormal (over/under voltage, over/under frequency, loss of phase, and phase rotation) Lamp off: 1# loss of power	
2# Power ●	Lamp illuminates: 2# power normal Lamp flashes: 2# power abnormal (over/under voltage, over/under frequency, loss of phase, and phase rotation) Lamp off: 2# loss of power	
1# Main ●	Lamp illuminates: 1# Priority (auto transfer and restore)	Both illuminates: “mutual backup (auto transfer and non-auto restore)”
2# Main ●	Lamp illuminates: 2# Priority (auto transfer and restore)	
1# Close ●	Lamp illuminates: 1# Supply	
2# Close ●	Lamp illuminates: 2# Supply	
Alarm ●	Lamp fast flashes: force open input alarm	
Auto/Manual Mode ●	Lamp illuminates: controller in Auto mode Lamp off: controller in Manual mode	
Genset Status ●	Lamp illuminates: genset start signal outputs Lamp flashes: genset start signal de-energized	




4.4 OPERATION

4.4.1 AUTO/MANUAL MODE SWITCH

When the controller is normally working, if auto/manual mode indicator is off, it means controller is in manual mode; it can switch into auto mode by pressing , the indicator will be normally light; then press  again to switch back to manual mode.

▲Note: after repower-on, controller mode depends on the mode in which the controller was last powered down. When the controller is powered off in manual mode, the controller is still in manual mode after repower-on.



4.4.2 MANUAL OPERATION

When controller is in manual mode, if press , 1# close relay outputs, and 1# close status indicator illuminated when 1# close status input detecting is active, and then 1# supply ramps on load; if press , 2# close relay outputs, and 2# close status indicator illuminated when 2# close status input detecting is active, and then 2# supply ramps on load; if press , breaker close relay output disconnected while 1# or 2# is closing, and breaker close relay outputs while 1# or 2# is closed.

4.4.3 AUTO OPERATION

In auto mode, controller can switch between 1# supply and 2# supply automatically.

4.4.4 MANUAL TEST

In manual mode, when genset start signal is active, press  can deactivate the genset start signal. When genset start signal is inactive, press  can activate the genset start signal.

5. ALARM

Controller has force open input (FO IN) alarm. When force open input is active, alarm indicator flashed with 5Hz frequency, simultaneously, controller switches ATS to breaking position; when force open input is inactive, controller closes/opens breaker normally.

6. WIRE CONNECTION




Fig.2 – Controller Rear Panel Drawing

Table 5 – Terminals Description

No.	Items	Function Description	Remark
1	N2	2# AC 3-phase 4-wire input	Single phase: connect with A2 and N2; B2 and C2 are not connected; 2-phase 3-wire: connect with A2, B2, and N2; C2 is not connected; 3-phase 3-wire: connect with A2, B2, and C2; N2 is not connected (special order required).
2	C2		
3	B2		
4	A2		
5	N1	1# AC 3-phase 4-wire input	Single phase: connect with A1 and N1; B1 and C1 are not connected;
6	C1		



No.	Items	Function Description	Remark
7	B1		2-phase 3-wire: connect with A1, B1, and N1; C1 is not connected; 3-phase 3-wire: connect with A1, B1, and C1; N1 is not connected (special order required).
8	A1		
9	Gen Start	Volt free normally close contact output	Rated capacity: AC7A/250V
10	Signal Output		
11	COM	Breaker close/open output common port	
12	1# Close Relay	Volt free normally open contact output	Rated capacity: 10A/250VAC
13	2# Close Relay	Volt free normally open contact output	Rated capacity: 10A/250VAC
14	Open Output	Volt free normally open contact output	Rated capacity: 7A/250VAC
15	NO		Rated capacity: 10A/250VAC
16	LO		Rated capacity: 10A/250VAC
17	FO IN	Force open input, when active, transfer ATS to breaking position.	Ground is active
18	1# Close Input	Detect 1# breaker close status, auxiliary contact input.	Ground is active
19	2# Close Input	Detect 2# breaker close status, auxiliary contact input.	Ground is active
20	Common Port	GND	
LINK	Communication Port	Communicate with PC and used for program update	Used with SG72 adaptor
F1	Fuse		Rated 10A 250VAC
F2	Fuse		Rated 10A 250VAC

7. DEFINITION AND RANGE OF PARAMETERS

Table 6 – Parameters Definition and Range Table (1)

No.	Items	Range	Default	Description
1	AC System	(1-4)	1	1: 3 Phase, 4 Wire (3P4W) 2: Single Phase, 2 Wire (1P2W) 3: 3 Phase, 3 Wire (3P3W) (special order required) 4: 2 Phase, 3 Wire (2P3W)
2	S1 Normal Delay	(1-7)	2	1: 1s 2: 5s 3: 10s 4: 20s 5: 30s 6: 45s 7: User defined(Default: 5s)
3	S2 Normal Delay	(1-7)	2	1: 1s 2: 5s 3: 10s 4: 20s 5: 30s 6: 45s 7: User defined(Default: 5s)
4	S1 Abnormal Delay	(1-7)	2	1: 1s 2: 5s 3: 10s 4: 20s 5: 30s 6: 45s 7: User defined(Default: 5s)
5	S2 Abnormal Delay	(1-7)	2	1: 1s 2: 5s 3: 10s 4: 20s 5: 30s 6: 45s 7: User defined(Default: 5s)
6	Close Delay	(1-7)	4	1: Continuous Close Enabled 2: 1s 3: 3s 4: 5s 5: 8s 6: 10s 7: User defined(Default: 5s)
7	Open Delay	(1-7)	3	1: 1s 2: 3s 3: 5s 4: 8s 5: 10s 6: 15s 7: User defined(Default: 5s)



No.	Items	Range	Default	Description
8	Breaker Interval Switch	(1-7)	1	1: 1s 2: 3s 3: 5s 4: 8s 5: 10s 6: 15s 7: User defined(Default: 1s)
9	Transfer Expired Delay	(1-7)	1	1: 0.5s 2: 1s 3: 2s 4: 3s 5: 4s 6: 5s 7: User defined(Default: 0.5s)
10	Gen Start Delay	(1-7)	4	1: 3s 2: 8s 3: 15s 4: 30s 5: 50s 6: 70s 7: User defined(Default: 30s)
11	Gen Stop Delay	(1-7)	6	1: 3s 2: 8s 3: 15s 4: 30s 5: 50s 6: 70s 7: User defined(Default: 90s)
12	Set Priority	(1-3)	1	1: S1 Priority 2: S2 Priority 3: No priority

NOTE:

- a) The parameters in this form can be set via computers and slave;
- b) When delay is “7: User defined”, parameter delay must be set via computer. If parameter is not set via computer, the delay is Default; if parameter has been set via computer, then the delay is the set value.

Table 7 - Parameters Definition and Range Table (2)




No.	Item	Range	Default	Description
1	Rated Voltage	(170-270)V	230	Provide base for over/under volt judge.
2	Rated Frequency	(50.0-60.0)Hz	50.0	Provide base for over/under frequency judge.
3	Over Voltage Warn	(0-1)	1	0: Disabled 1: Enabled
4	Over Volt Set Value	(100-120)%	115	Threshold value
5	Over Volt Return Value	(100-120)%	113	Return value
6	Under Voltage Warn	(0-1)	1	0: Disabled 1: Enabled
7	Under Volt Set Value	(70-100)%	75	Threshold value
8	Under Volt Return Value	(70-100)%	77	Return value

No.	Item	Range	Default	Description
9	Over Frequency Warn	(0-1)	1	0: Disabled 1: Enabled
10	Over Frequency Set Value	(100-120)%	110	Threshold value
11	Over Frequency Return Value	(100-120)%	104	Return value
12	Under Frequency Warn	(0-1)	1	0: Disabled 1: Enabled
13	Under Frequency Set Value	(80-100)%	90	Threshold value
14	Under Frequency Return Value	(80-100)%	96	Return value
15	Loss of Phase	(0-1)	1	0: Disabled 1: Enabled (fixed delay as 3s)
16	Phase Sequence Wrong	(0-1)	0	0: Disabled 1: Enabled (fixed delay as 3s)
17	Module Address	(1-254)	1	Address that communicates with PC software

▲NOTE: The parameters in this form can be set via computers.

8. PARAMETERS SETTING

8.1 PARAMETERS SETTING MODE

In manual mode, enter into parameters setting mode by pressing  for 8s and manual/auto indicator  and gen status indicator  flash; ①, ②, ③, ④ indicators illuminate. LED numbers please to see the following picture.













Fig.3 – Parameter Configuration

▲NOTE: At this moment, press  will be back to normal mode after LED flash.

8.2 PARAMETERS SETTING

When it entered into parameter setting mode, users can adjust parameters by pressing . And ④ and ⑦ LEDs are illuminated. ①, ②, ③, ④ indicators mean setting items numbers (currently item number is 1); ⑤, ⑥, ⑦ indicators mean these parameter values (currently parameter value is 1). Configurable parameter list please check “Table 6 – Parameters Definition and Range Table (1)” of item 7.

Specific settings are as below:

- 1) Select setting number which needs to adjust by pressing  and .
- 2) Enter into setting status by pressing  and ⑦ indicator flashes;
- 3) After set this parameter by pressing  and , and press the key to save the value.
- 4) Hold and press  after all parameters are configured, and release  when all LEDs flash, which means parameters are all saved and then will return to normal mode.

▲NOTE: See “Table 8 Parameter Value Comparison” for the values corresponding of LED indicators.


▲NOTE: after parameters configured completely, users need to press  to back to the normal mode to save the parameters. Otherwise, the setting parameters will be lost after controller power outage.

Table 8 – Parameter Value Comparison

Parameter Serial No. LED Indicate				Value	Parameter Value LED Indicate			Value
①	②	③	④		⑤	⑥	⑦	
○	○	○	●	1	○	○	●	1
○	○	●	○	2	○	●	○	2
○	○	●	●	3	○	●	●	3
○	●	○	○	4	●	○	○	4
○	●	○	●	5	●	○	●	5
○	●	●	○	6	●	●	○	6
○	●	●	●	7	●	●	●	7
●	○	○	○	8				
●	○	○	●	9				
●	○	●	○	10				
●	○	●	●	11				
●	●	○	○	12				

8.3 RESET TO DEFAULT

In parameter setting mode, press , ,  and  LEDs illuminated, and  LED flashes.

After pressing ,  LED illuminates for 2s, indicating that the factory value has been restored.

Meanwhile, all LEDs flash for 3 times and return back to the normal mode.

▲NOTE: if needn't to restore to factory value, press  to return to the normal mode after LED flashes.

9. TYPICAL APPLICATION




Fig.4 – ATyS d M Application Drawing




Fig.5 – ATyS d Application Drawing




Fig.6 – VITZRO/FEITENG ATS Application Drawing

NOTE: Please conference the above drawings for wiring. The actual wiring on site is subject to the ATS switch wiring instructions. And the capacity of the fuse should be selected according to the actual power consumption at the site, which cannot be based on the fuse capacity in the drawing.




Fig.7 – LO/NO Output Internal Wiring Connection

NOTE: F1 and F2 specification is 10A/250VAC, if using LO/NO as ATS's power supply, the max. circuit current of ATS is 10A.




Fig.8 – 2 Phase 3 Wire Connection




Fig.9 – Single Phase 2 Wire Connection

NOTE: The above drawing shows the wiring method is the AC phase voltage of 220V. If the AC phase voltage is 110V in actual use, please contact our technical personnel to confirm the specific wiring method.

10. OVERALL DIMENSION AND PANEL CUTOUT

10.1 CASE DIMENSION

Unit: mm




Fig.10 – Overall Dimensions

10.2 CUTOUT

The controller has three installation ways: panel built-in, internal 35mm slideway and internal screw mounting. Panel built-in and internal screw mounting are as below:




Fig.11 – Cutout Dimensions

10.3 INSTALLATION




Fig. 12 – Panel Built-in Installation




Fig.13 – 35mm Sideway Installation




Fig.14 – Internal Screw Installation

11. TROUBLESHOOTING

Tale 9 - Troubleshooting

Symptom	Possible Solutions
Controller inoperative	Check connections and voltages of 1# and 2# power; Check F1 or F2 fuse
Controller displays normal but switch not activate	Check ATS; Check the connections between controller and ATS.
1# or 2# power LED flashes	Check whether AC voltage is normal or not.
Alarm LED flashes	If switch close failure alarms, please check switch auxiliary contact wiring.

SmartGen